

720 Middle Ground Blvd. Newport News, VA 23606 (757) 873-6602 – (800) 227-6602 – (757) 873-0212 FAX

Measuring for motorized window shades

Motorized window shades must be mounted on a surface in which the front surface of the top, sides and bottom of the mounting surface are all in the same plane. The shade components must be mounted level and plumb. If you are mounting shades on commercial aluminum window frames it is not recomended that the shades be mounted inside the frame opening because it then becomes difficult to route the wiring into the shade housing and also dimensions are much more critical. It is recommended that the shade components be mounted on the face of the window frames allowing wiring access from the ceiling through the top of the shade housing. When ordering please indicate the actual overall width and height of each shade unit. The diagram below shows what areas of the windows must be measured to properly order the shades.

